

QuickShifter easy (iQSE)

User's Guide

For the most current version of this document, please visit:
www.healtech-electronics.com/iQSE

1. Foreword

Congratulations on your purchase of a *HealTech QuickShifter easy* (iQSE) - next generation standalone quickshifter module.

The iQSE is the only quickshifter module on the market which utilizes Bluetooth technology for setup and function tests. Can even be disabled with a few taps to restore factory condition e.g. for servicing the bike.

The unit comes with a special ring sensor which is extremely simple to install and works on all motorcycles (also with reverse/race shift pattern). It's a robust design, has no moving parts and works in every situation. Sensitivity (threshold) can be adjusted precisely to your riding style.

We offer the widest range of Plug 'n go harness kits which suit hundreds of different motorcycles.

There are two iQSE models. Make sure you received the correct one:

- The iQSE-1 is for bikes with TCI (Transistor Controlled Ignition). TCI is the current technology and most bikes on the road today require the iQSE-1.
- The iQSE-2 is for bikes with CDI (Capacitor Discharge Ignition).

2. Device compatibility

iOS devices:

All phones and tablets running iOS 8.1 or later.

"Made for iPhone" and "Made for iPad" mean that an electronic accessory has been designed to connect specifically to iPhone or iPad, respectively, and has been certified by the developer to meet Apple performance standards.

iPhone, iPad and iPod touch are trademarks of Apple Inc. registered in the U.S. and other countries.

Android devices:

All phones and tablets running Android 2.3 or later.

3. How to Setup the unit

1. **Install the module and sensor** as per the supplied Install Guide.
2. **Install the *QuickShifter easy (iQSE)* free app** on your device.
In the *App Store* or *Play Store*, search for **HealTech** to find the app.
3. **Turn the ignition key ON.**
The iQSE LED light should light up in GREEN color then change to solid RED. This confirms that the unit has power and ready for use.
If the LED turns off in a short while or does not light up, you need to have the engine running to establish the Bluetooth connection.
4. **Open the iQSE app** and **connect to the module from the app** as instructed. The pairing code is always **4325** for the iQSE.
5. **Start the Setup Wizard** in the app and follow the instructions on the screen.
6. **Take a test ride and fine-tune the settings.** For information about the setup parameters, refer to the help texts you see in the iQSE app at the bottom of each menu screens.

4. How to use the QuickShifter

- You may do clutchless upshifts only during acceleration, i.e. at partial to full throttle, well above idle speed.
- Always use the clutch under these conditions:
 - selecting first gear
 - finding neutral
 - shifting to 2nd gear if it's not smooth without clutch on your bike
 - during deceleration/braking
 - when hitting the rev limiter
 - when the engine does not pull
- You may do clutchless downshifts with partial throttle from the higher (4-6) gears only if the shifts are smooth and effortless on your bike and the shift lever is not stiff. Otherwise, use the clutch for downshifts.
- Be sure you always do quick, confident and complete shift movements with your foot, until the lever stops. Adjust the shift lever position if necessary to ensure effortless and complete shift movement with your foot.
When the power is cut, there's a limited time (typically less than 90ms) while the gearbox is being unloaded and clutchless shift is possible. After this time the gearbox is loaded again due to engine braking. If you change the gear slowly, you may hit false neutral or you can't make the shift at all.
- If the shifts are not smooth, do not stress your gearbox. Use the clutch until you make the necessary changes.

5. Frequently Asked Questions

Please read our iQSE FAQ before sending a question:
www.healtech-electronics.com/app/iqse/faq_en

6. Troubleshooting

In case of problems or concerns, please check out our Troubleshooting Guide:
www.healtech-electronics.com/app/iqse/trb_en

7. LED status codes

Solid RED	Unit is powered up. Engine is not running or RPM signal is not received.
Solid GREEN	Unit is powered up. Engine is running (RPM signal is received).
Flashing RED	Error detected. Connect to the application to see the problem.
Flashing GREEN	Bluetooth interface is in standby (typically, while riding). Cycle the ignition key if you wish to connect.
Alternating color	Shift signal detected, data is sent to the module or firmware update is in progress.

8. Warranty

Disclaimer: Do not attempt to install the product if you don't have basic mechanical skills. HealTech Electronics Ltd. and its distributors shall not be liable for any loss or damage caused by improper installation or setup. Please read the instructions carefully.

If the gearshifts are not smooth, do not stress your gearbox. Use the clutch until you make the necessary changes.

To ensure trouble-free operation from the start, all units have been extensively tested prior to shipment. For this reason, please make sure you followed the install steps carefully and check the connections and settings before you report a problem.

The product is covered by our 2-year replacement warranty from the date of purchase.

The warranty does not apply to product that has been subjected to misuse, fitted incorrectly or there's a visible damage e.g. from a crash.

Web: www.healtech-electronics.com

Email: support@healtech-electronics.com